

ANANDA


Help Manual

Cadence Sensor

The content of this information is subject to change without notice


1. Check the harness for damage and the connector for loosening or falling.

①



2. Check whether the sensor is loose or falls off.

②



3. Replace cadence sensor.
4. Replace controller.